

Why is my device not syncing with the app?

1. Go to the profile section by tapping your profile picture in the top left corner.
2. Navigate to "Connections."
3. Check your device connection. If already connected, tap to disconnect and then connect again.
4. Go to the fitness page and wait a few seconds for the data to refresh.
5. If you still encounter issues, please contact us at support@healthmov.com

Revision #1

Created 20 June 2024 13:52:56 by Saloni

Updated 20 June 2024 13:53:22 by Saloni